



**GENERAL NOTES:**

THESE ARE SUGGESTED DETAILS. PROJECT REQUIREMENTS & CONDITIONS MAY VARY.

ISOLATE ALL COPPER & ALUMINUM MATERIALS FROM FERROUS METALS BY APPLICATION OF DECK SEAL TAPE.

USE STAINLESS STEEL FASTENERS AT COPPER OR LEAD COATED COPPER FLASHINGS & DRAINS.

REFER TO ARCHITECTURAL & STRUCTURAL DRAWINGS AND SPECIFICATIONS FOR ADDITIONAL INFORMATION REGARDING PLYWOOD SHEATHING, FRAMING, BLOCKING AND SHEET METAL INSTALLATION.

**EXCEL-COAT  
FIRE SYSTEM**

**PLYWOOD  
WALL TO DECK**

**MARCH 2008**

**EXCELLENT COATINGS  
INTERNATIONAL**

10880 POPLAR AVENUE  
FONTANA, CA. 92337  
(800) 473-3817

**DETAIL**

**16**

**ALTERNATIVE**