



GENERAL NOTES:

THESE ARE SUGGESTED DETAILS. PROJECT REQUIREMENTS & CONDITIONS MAY VARY.

ISOLATE ALL COPPER & ALUMINUM MATERIALS FROM FERROUS METALS BY APPLICATION OF DECK SEAL TAPE.

USE STAINLESS STEEL FASTENERS AT COPPER OR LEAD COATED COPPER FLASHINGS & DRAINS.

REFER TO ARCHITECTURAL & STRUCTURAL DRAWINGS AND SPECIFICATIONS FOR ADDITIONAL INFORMATION REGARDING PLYWOOD SHEATHING, FRAMING, BLOCKING AND SHEET METAL INSTALLATION.

**EXCEL-COAT
FIRE SYSTEM**

**PLYWOOD
SCUPPER**

MARCH 2008

**EXCELLENT COATINGS
INTERNATIONAL**

10880 POPLAR AVENUE
FONTANA, CA. 92337
(800) 473-3817

DETAIL

19